

# **USER'S MANUAL**

## **Series MPT390 M6**








Via Enrico Fermi, 57/59 - 10091 ALPIGNANO (TO)  
☎ Telefono: +39 (0)11 9664616 Fax: +39 (0)11 9664610  
E-mail: [srlmect@mect.it](mailto:srlmect@mect.it) - C.F. e P.I. 04056380019



ME4014\_16  
07/16



**INDEX**

INDEX.....	1
 1.0 GENERAL POINTS .....	3
1.1 TECHNICAL CHARACTERISTICS .....	3
1.2 DISPLAY MESSAGES .....	4
1.3 MPT INSTRUMENT CONNECTION OVERVIEW .....	5
 2.0 INSTALLATION NOTES .....	9
2.1 INSTRUMENT WITH HEATING OR COOLING CONTROL .....	9
2.1.1 DIAGRAM MENU WITH HEATING OR COOLING CONTROL .....	10
2.2 INSTRUMENT WITH HEATING AND COOLING CONTROL .....	16
2.2.1 DIAGRAM MENU WITH HEATING AND COOLING CONTROL .....	17
2.3 INSTRUMENT WITH SERVOMOTOR CONTROL .....	23
2.3.1 DIAGRAM MENU WITH SERVOMOTOR CONTROL .....	24
2.4 INSTRUMENT WITH A VALVE CONTROL .....	29
2.4.1 DIAGRAM MENU WITH A VALVE CONTROL .....	30
2.5 SET POINT MODIFICATIONS.....	35
2.6 HB ANALOGUE INPUT.....	36
2.7 ANALOGUE INPUTS .....	36
2.8 FUNCTION OFF-SET (OFFS).....	36
2.9 SET UP AL1 and AL2 .....	36
 3.0 ANALOGUE OUTPUT (option) .....	37
3.1 ANALOGUE OUTPUT FOR MOTORIZED VALVE .....	38
3.2 ANALOGUE OUTPUT FOR READOUT .....	38
4.0 REGULATIONS .....	39
4.1 PID TYPE REGULATION.....	39
4.1.1 CUTBACK FUNCTION.....	40
4.1.2 SELF-TUNING FUNCTION (setu).....	41
4.2 ON-OFF TYPE REGULATION.....	42
4.3 SOFT-START FUNCTION (sost).....	43
 5.0 RAMP SET UP .....	44
5.1 KEY FUNCTIONS .....	45
5.2 DIAGRAM RAMP MENU.....	46
 6.0 SERIAL OUTPUT .....	50
6.1 DATA READING FROM HOST TO INSTRUMENT MPT.....	51
6.2 DATA TRANSMISSION FROM MPT TO HOST .....	52
6.3 DATA WRITING FROM HOST TO MPT .....	53
6.4 COMMAND CODES.....	54

## MPT390 M6

6.5 STATUS WORD .....	57
6.6 TRANSMISSION OF HEXADECIMAL VALUES .....	57
6.7 RAMP PROGRAMMING WITH SERIAL LINE.....	58
6.8 AN EXAMPLE IN BASIC LANGUAGE .....	58
 7.0 PASSWORD FUNCTION .....	59
8.0 DEFAULT PARAMETERS (dEF).....	59
 9.0 NOTES .....	59

## MPT390 M6



### 1.0 GENERAL POINTS

The instruments of the family " MPT/390/M6" represent a series of " Single Loop" microprocessor temperature regulators in the standard 48x96 dimensions (120 mm. depth.)

The complete version of the MPT/390/M6 instrument has the following technical characteristics:

- 1- Input from Thermoresistance PT100 ( scale  $-40.0 \div 200.0^{\circ}\text{C}$  or  $-40 \div 800^{\circ}\text{C}$ ), or from thermocoupling Fe/CO ( $0 \div 600^{\circ}\text{C}$ ) and Cr/Al ( $0 \div 1200^{\circ}\text{C}$ ) and Pt-Pt/Rh ( $0 \div 1710^{\circ}\text{C}$ ), or from voltage (  $0 \div 10 \text{ V}$  ) and current ( $0/4 \div 20 \text{ mA}$ ) selectable from the keyboard.
- 2- Two display to see Set-Point and Process Value and 6 keys for an easy programmability.
- 3- a exchange relay for the regulation of the main intervention point, with regulation ON-OFF or PID.
- 4- Static open collector NPN output for solid state relay.
- 5- Servomotor control drive.
- 6- Soft Start and Self Tuning functions.
- 7- Ramp program with 3 programs with 8 steps each one

Available options:

- 1- Two contact relay for ( minimum or maximum ) alarms signals or for the cooling process control.
- 2- Ammeter input for heater breaker controls with blinking led and alarm relay (HB)
- 3- Opto-isolated or standard analogue output (  $0 \div 10 \text{ V}$ ,  $4 \div 20 \text{ mA}$  or  $0 \div 20 \text{ mA}$  ) for PID control or read out value.
- 4- Opto-isolated or standard bi-directional serial transmission line for dialogue with host-computer.

### 1.1 TECHNICAL CHARACTERISTICS

Table 1

<b>Sensors used</b>	thermoresistance PT100 at 2 or 3 wires: <b>PT r:</b> $-40.0 \div 200.0^{\circ}\text{C}$ ; <b>Pt E:</b> $-40 \div 800^{\circ}\text{C}$ ; <u>Thermocouplings:</u> <b>Fe/Co (J):</b> $0 \div 600^{\circ}\text{C}$ ; <b>Cr/Al (K):</b> $0 \div 1200^{\circ}\text{C}$ ; <b>Pt/Pt-10% Rh (S):</b> $0 \div 1710^{\circ}\text{C}$
<b>Analogue inputs</b>	$0 \div 10 \text{ V} - 0 \div 20 \text{ mA} - 4 \div 20 \text{ mA}$
<b>Input current resistance</b>	$20 \Omega$
<b>Input voltage resistance</b>	$1 \text{ M}\Omega$
<b>Data reading precision</b>	$0.5\% \text{ F.S. } \pm 1 \text{ digit } \pm 1 \text{ degree}$

## MPT390 M6

<b>Controls</b>	on-off / pid
<b>On-Off Set Up</b>	HY in the range 0 ÷ F.S. °C/°F
<b>Pid Set Up</b>	<b>cycle time in the range:</b> 1 ÷ 200 sec
	<b>proportional band:</b> 0 ÷ F.S. °C/°F
	<b>integrative time:</b> 0 ÷ 6000 sec.
	<b>derivative time:</b> 0 ÷ 600 sec
	<b>cutback const.:</b> 0 ÷ F.S. °C/°F
<b>Alarms</b>	of min. or max in the range: 0 ÷ F.S. °C/°F
<b>Main Output</b>	Exchange relay 220V /5A
<b>Alarm output</b>	relay contact 220V /5A
<b>Power supply</b>	90 ÷ 260 Vac/Vdc
	20÷30Vac/Vdc
<b>Analogue outputs</b>	0 ÷ 10 V – 0 ÷ 20 mA – 4 ÷ 20 mA
<b>Max load for current output</b>	300 Ω
<b>Min load for voltage output</b>	1 KΩ
<b>Max voltage given</b>	10 V
<b>Max current given</b>	20 mA
<b>Resolution</b>	12 bits
<b>Heater breaker control</b>	by TA/1 A
<b>Dimensions</b>	48 x 96 120 mm.
<b>Mounting plate</b>	44.5 mm (w) x 92.5 mm. (h)

### 1.2 DISPLAY MESSAGES

The following table shows a summary of all the messages that the instrument can show on the display. Some are operating signals, others are indications of anomalies or non performance. In these cases we ask you to consult the instruction manual and the service centre, as necessary.


**Table 2**

r01.2	Release Software
LO	temperature under input range, or connection error for the PT100 sensor
HI	temperature above input range
Err	sensor interrupted or malfunctioning input circuit
Err1, Err2, Err3, Err4	See “Self-Tuning function”
Abort	See “Soft Start” and “Self Tuning” functions

# MPT390 M6

## 1.3 MPT INSTRUMENT CONNECTION OVERVIEW

### DESCRIPTION OF THE FRONT COMMANDS



PV-Upper Display: temperature as read by sensor

SP-Lower Display: set-point (power percentage on manual control)


Led AL1: alarm status indication or cooling action or servomotor control drive (if requested )


Led AL2: alarm 2 status indication (if requested)

Led Rp: ramp function indication


Led HB: load break indication (if requested)


Led ON: load control indication


Key  : access to the programming functions

Key  : increase set-point. Used for programming function

Key  : decrease set-point. Used for programming function

Key  : Start/Stop function. Only in Ramp regulation (disabled of the menu by item “AbtS”)


Key  : enter the enable Ramp programs (disabled of the menu by item “Abtr”)

Key  : fast exit from the main or ramp menu

Key  +  Keys : % power indication

# MPT390 M6

## DESCRIPTION OF THE TERMINAL BOARD



- Terminal 1: principal exchange relay ( NO contact ).
- Terminal 2: principal exchange relay ( COM contact ).
- Terminal 3: principal exchange relay ( NC contact ).
- Terminals 4 - 5: contact NO of alarm relay 1 (if requested)
- Terminals 6 - 7: contact NO of alarm relay 2 (if requested)
- Terminals 8 - 9: static output for main operations (terminal 8: power supply, for external static relay, of around 16 Vdc).
- Terminals 11 - 12: load control break HB (if requested)
- Terminals 13 - 15: instrument power supply. Between terminals 13 and 15 power at 90/260 Vac/Vdc, or 12/30Vac/Vdc if requested.
- Terminals 20 ÷ 23: analogue outputs ( if requested ).
- Terminals 16 ÷ 19: serial output connections (if requested).
- Terminals 24 ÷ 30: inputs for sensor.


### Thermocoupling sensor

Terminal 28 = IN-  
Terminal 27 = IN+

### Thermoresistance sensor

Terminal 30 = PT100  
Terminal 29 = PT100;  
Terminal 28 = GND (third wire)

### CONNECTIONS PT100






## MPT390 M6


For thermoresistance connection pay attention to the line resistance: if too high there may be some errors in readout. Use the same kind of wire for the three connections. If shielded cable is used, connect the shield to ground at one end only.

### THERMOCOUPLING CONNECTIONS




Thermocouplings must be isolated. For thermocoupling connection use only compensated wire for the type of thermocouple in use. If shielded cable is used, connect the shield to ground at one end only.


### CURRENT INPUT CONNECTIONS




### VOLTAGE INPUT CONNECTIONS



**RELAY CONNECTIONS**




**STATIC OUTPUTS CONNECTIONS**



Be careful: this output is not isolated and may be used for an external solid state relay with double isolation between instrument and power line.

**SERVOMOTOR CONNECTIONS**



**SERIAL OUTPUTS AND ANALOGUE OUTPUTS CONNECTIONS**

See dedicated paragraphs.



## 2.0 INSTALLATION NOTES

1. Copy the connection schemes on pages 6, 7 and 8 taking into account the following points:
  - a- the instrument can operate with analogue inputs or temperature sensors of both thermoresistance and thermocoupling types. Only one of this sensors can be connected (attach the connection only for the chosen sensor, leaving free the other connections.).
  - b- the connector diagram shows all the possible options that the instrument may have; if certain options are not required then the relative connections are not necessary.
2. Follow the instructions of the paragraph:
  - 2.1: for heating or cooling control
  - 2.2: for heating and cooling control
  - 2.3: for a servomotor control
  - 2.4: for a valves control
3. Follow the instructions of the paragraph "Regulations" to optimise control parameters.
4. If the instrument is requested with ammeter load control, it is necessary to consider the paragraph "Function -HB-"
5. If the instrument is requested with "OAP" or "OAC" option, it is necessary to consider the paragraph "ANALOGUE OUTPUT".
6. If the instrument is requested with the serial output, see the paragraph "SERIAL OUTPUT".

### **2.1 INSTRUMENT WITH HEATING OR COOLING CONTROL**

Heating (tCO<sub>n</sub> = in) or cooling (tCO<sub>n</sub> = dir) regulation is performed by main relay; it is possible to use two alarm outputs (if requested) and the analogue output (if requested) that varies with the temperature readout.

Program the instrument following the table below; by "Exit" key it is possible to escape immediately from the menu.

To set up control parameters see paragraph "Regulations".


For an automatic set point function, see paragraph "Ramp programming".

**Beware:** If out of range MENUs item are programmed, they are proposed again at the maximum possible value.

To reset to factory default parameters you can see the paragraph "Default parameters".

# MPT390 M6

## 2.1.1 DIAGRAM MENU WITH HEATING OR COOLING CONTROL



Search for the item to change, shown in the upper display using key **Enter**


The value to change is shown on the lower display. If you must change a number, use the key to increment the blinking digit,

and the **SP** key to shift the blinking digit, and if you must select an item, use the **SP** key.

In either case use the **Enter** key to confirm the input and go in the menu.

To exit the menu, press **Exit** : the modified parameters will be stored.

# MPT390 M6



# MPT390 M6

## Table 3

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
1	enter	PASS	0 000	In this phase the instrument asks for the Password in order to save the data already programmed. The number memorized by the factory is 0, but any number between 0 and 9999 can be memorized by writing where CPAS appears (next displayed item).	Pp 59
2	SP- ▶	PASS	0 <u>0</u> 00	Set Up Procedure. To digit the desired number touch the key " SP- ▶ " to move the flashing number to the right.	
3	SP+ ▲	PASS	0 <u>1</u> 00	Touch the key " SP+ ▲ " to increase the flashing number	
4	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
5	enter	SCAL	°C	Temperature scale: Choose the type of scale required. Set the requested scale (°C or °F) by "SP+ ▲" and confirm with "enter".	
6	enter	InP	PtE	Choose the type of sensor required. Touch the key "SP+ ▲ " until the chosen input appears on "SP" display: FECO = Fe/CO (0 ÷ 600 °C) (J) CrAL = Cr/Al (0 ÷ 1200 °C) (K) PtPr = Pt/Pt-Rh (0 ÷ 1710°C) (S) PtE = PT100 (-40 ÷ 800 °C) Ptr = PT100 (- 40.0 ÷ 200.0 °C) 0 10 = analogue input 0-10V 0 20 = analogue input 0-20mA 4 20 = analogue input 4-20mA To change this item use the "SP+ ▲ " key and confirm by "enter"	Pp 36
7	enter	PdEC	0.000	Decimal point for analogue input. Touch the key "SP+ ▲ " to set the decimal point and confirm with "enter"	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
8	enter	IS t	0000	Set the requested reading with the beginning of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
9	enter	FS t	1000	Set the requested reading with the full scale of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
10	enter	Out	rISC	Choose rISC for heating regulation with the main relay. Set the requested regulation by “SP+ ▲” and confirm with “enter“.	
11	enter	LISP	0 000	Lower limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
12	enter	LSSP	0 000	Upper limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
13	enter	OFFS	0 000	Using the number "OFFS" it is possible to correct the displayed temperature by adding or subtracting a constant written in the display "PV". To digit the number follow the procedure described in points 2 and 3	
14	enter	Hb	0 100	If the “HB” option is installed on the instrument, set the desired value for the load current percentage. To digit the number follow the procedure described in points 2 and 3.	
15	enter	S.AL1	tEnP	Selection the kind of working Alarm1 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
16	enter	AbA1	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	Pp 36
17	enter	AL1	0 000	Alarm value set up (if requested). To digit the value see steps 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
18	enter	ISA1	001	Alarm 1 hysteresis set up	Pp 36
19	enter	C A1	nA	Possibility of inverting the relay 1 function nA = normally open nC = normally closed Set the requested regulation by “SP+ ▲ ” and confirm with “enter“.	Pp 36
20	enter	S.AL2	tEnP	Selection the kind of working Alarm2 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	
21	enter	AbA2	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	



## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
22	enter	AL2	0 000	Alarm 2 value set up (if requested). To input the value see step 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
23	enter	ISA2	001	Alarm 2 hysteresis set up	
24	enter	C A2	nA	Possibility of inverting the second relay function nA = normally open nC = normally closed Set the requested regulation by "SP+ ▲" and confirm with "enter".	
25	enter	OUAn	0 10	If analogue outputs are requested touch the key "SP+ ▲" until the output required appears on the display and then confirm with "enter". 0 10 = output 0 ÷ 10 V 0 20 = output 0 ÷ 20 mA 4 20 = output 4 ÷ 20 mA	Pp 36
26	enter	tCO n	In	Control type: In = reverse function ( main relay = heating ) DIr = direct function To change this item use the "SP+ ▲" key and confirm by "enter"	
	Exit	Read out	Set point		

## **2.2 INSTRUMENT WITH HEATING AND COOLING CONTROL**

The instrument with heating and cooling control can be used only if the instrument has the alarm relay. In this function, the main relay makes the heating regulation and the alarm relay 1 makes the cooling regulation. The analogue outputs ( if requested ) change in according to the Process Value.

The alarm relay 2 (if requested) can be used for temperature control.

Program the instrument following the table below; by “Exit” key it is possible to escape immediately from the menu. Selecting heating-cooling control the instrument also gives the cooling dead-band item (bAnr).


To set up control parameters see paragraph "Regulations".

For an automatic set point function, see paragraph "Ramp programming".

**Beware:** If out of range menu's item are programmed, they are proposed again at the maximum possible value. To reset to factory default parameters you can see the paragraph “Default parameters”.

# MPT390 M6

## 2.2.1 DIAGRAM MENU WITH HEATING AND COOLING CONTROL



Search for the item to change, shown in the upper display using key **Enter**

The value to change is shown on the lower display. If you must change a number, use the key to increment the blinking digit,


and the **SP** key to shift the blinking digit, and if

you must select an item, use the **SP** key.

In either case use the **Enter** key to confirm the input and go in the menu.

To exit the menu, press **Exit** :  
the modified parameters will be stored.

# MPT390 M6



# MPT390 M6

## Table 4

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
1	enter	PASS	0 000	In this phase the instrument asks for the Password in order to save the data already programmed. The number memorized by the factory is 0, but any number between 0 and 9999 can be memorized by writing where CPAS appears (next displayed item).	Pp 59
2	SP- ▶	PASS	0 <u>0</u> 00	Set Up Procedure. To digit the desired number touch the key " SP- ▶ " to move the flashing number to the right.	
3	SP+ / ▲	PASS	0 <u>1</u> 00	Touch the key " SP+ ▲ " to increase the flashing number	
4	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
5	enter	SCAL	°C	Temperature scale: Choose the type of scale required. Set the requested scale (°C or °F) by "SP+ ▲" and confirm with "enter".	

**MPT390 M6**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on SP display</b>	<b>NOTES</b>	<b>See page</b>
<b>6</b>	enter	InP	PtE	Choose the type of sensor required. Touch the key “SP+ ▲ “ until "SP" display appears on the chosen Input: FECO = Fe/CO (0 ÷ 600 °C) (J) CrAL = Cr/Al (0 ÷ 1200 °C) (K) PtPr = Pt/Pt-Rh (0 ÷ 1710°C) (S) PtE = PT100 (-40 ÷ 800 °C) Ptr = PT100 (- 40.0 ÷ 200.0 °C) 0 10 = analogue input 0-10V 0 20 = analogue input 0-20mA 4 20 = analogue input 4-20mA To change this item use the “SP+ ▲ “ key and confirm by “enter”	Pp 36
<b>7</b>	enter	PdEC	0.000	Decimal point for analogue input. Touch the key “SP+ ▲ “ to set the decimal point and confirm with "enter"	
<b>8</b>	enter	IS t	0000	Set the requested reading with the beginning of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>9</b>	enter	FS t	1000	Set the requested reading with the full scale of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>10</b>	enter	Out	rIrA	rIrA: heating-cooling Set the requested regulation by “SP+ ▲ ” and confirm with “enter“.	
<b>11</b>	enter	LISP	0 000	Lower limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
<b>12</b>	enter	LSSP	0 000	Upper limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35

**MPT390 M6**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on SP display</b>	<b>NOTES</b>	<b>See page</b>
<b>13</b>	enter	OFFS	0 000	Using the number "OFFS" it is possible to correct the displayed temperature by adding or subtracting a constant written in the display "PV". To digit the number follow the procedure described in points 2 and 3	
<b>14</b>	enter	Hb	0 100	If the "HB" option is installed on the instrument, set the desired value for the load current percentage. To digit the number follow the procedure described in points 2 and 3.	
<b>15</b>	enter	S.AL2	tEnP	Selection the kind of working Alarm2 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the "SP+ ▲" key and confirm by "enter"	
<b>16</b>	enter	AbA2	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the "SP+ ▲" key and confirm by "enter"	
<b>17</b>	enter	AL2	0 000	Alarm 2 value set up (if requested). To digit the value see step 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
<b>18</b>	enter	ISA2	001	Alarm 2 hysteresis set up	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
19	enter	C A2	nA	Possibility of inverting the second relay function nA = normally open nC = normally closed Set the requested regulation by "SP+ ▲" and confirm with "enter".	
20	enter	OUn	0 10	If analogue output is requested touch the key "SP+ ▲" until the output required appears on the display and then confirm with "enter". 0 10 = output 0 ÷ 10 V 0 20 = output 0 ÷ 20 mA 4 20 = output 4 ÷ 20 mA	Pp 36
21	enter	tCO n	In	Control type: In = reverse function ( main relay = heating ) DIr = direct function To change this item use the "SP+ ▲" key and confirm by "enter"	
27	enter	bAnr	10.0	Touch "enter" the key until the item bAnr appears = cooling dead band (see paragraph)	
	Exit	Read out	Set point		



## MPT390 M6

### **2.3 INSTRUMENT WITH SERVOMOTOR CONTROL**

The UnOt function can be used only if the instrument has the alarm relay. In this function, the main relay together with alarm relay control the servomotor. Selecting the item “ out = UnOt “, there are other two values to set for the control: “ time “ ( time that the servomotor needs for its cycle ) and “ bAnO “ ( dead band for the servomotor ). In “ time “ it is necessary to set the full scale time ( in seconds and tenth of second ) that the servomotor needs to complete its cycle, while in “bAnO“ it is possible to set an interval ( expressed in percentage of “time “ ) where the servomotor doesn't have the control. Example: full scale “time “ 90 seconds, dead band: 10%. The displacements shorter than 9 seconds are inhibited.

The analogue outputs ( if requested ) change in according to the Process Value.

The alarm relay 2 (if requested) can be used for temperature control.

Program the instrument following the table below; by “Exit” key it is possible to escape immediately from the menu.

To set up control parameters see paragraph "Regulations".


For an automatic set point function, see paragraph "Ramp programming".

**Beware:** If out of range menu's item are programmed, they are proposed again at the maximum possible value.

To reset to factory default parameters you can see the paragraph “Default parameters”.

# MPT390 M6

## 2.3.1 DIAGRAM MENU WITH SERVOMOTOR CONTROL



Search for the item to change, shown in the upper display using key **Enter**

The value to change is shown on the lower display. If you must change a number, use the key to increment the blinking digit,


and the **SP** key to shift the blinking digit, and if

you must select an item, use the **SP** key.

In either case use the **Enter** key to confirm the input and go in the menu.

To exit the menu, press **Exit** :  
the modified parameters will be stored.

# MPT390 M6



MPT390 M6

Table 5

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
1	enter	PASS	0 000	In this phase the instrument asks for the Password in order to save the data already programmed. The number memorized by the factory is 0, but any number between 0 and 9999 can be memorized by writing where CPAS appears ( next displayed item).	Pp 59
2	SP- ▶	PASS	0 0 00	Set Up Procedure. To digit the desired number touch the key " SP- ▶ " to move the flashing number to the right.	
3	SP+ ▲	PASS	0 1 00	Touch the key " SP+ ▲ " to increase the flashing number	
4	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
5	enter	SCAL	°C	Temperature scale: Choose the type of scale required. Set the requested scale (°C or °F) by "SP+ ▲ " and confirm with "enter ".	
6	enter	InP	PtE	Choose the type of sensor required. Touch the key "SP+ ▲ " until "SP" display appears on the chosen input: FECO = Fe/CO (0 ÷ 600 °C) (J) CrAL = Cr/Al (0 ÷ 1200 °C) (K) PtPr = Pt/Pt-Rh (0 ÷ 1710°C) (S) PtE = PT100 (-40 ÷ 800 °C) Ptr = PT100 (- 40.0 ÷ 200.0 °C) 0 10 = analogue input 0-10V 0 20 = analogue input 0-20mA 4 20 = analogue input 4-20mA To change this item use the "SP+ ▲ " key and confirm by "enter"	Pp 36

**MPT390 M6**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on SP display</b>	<b>NOTES</b>	<b>See page</b>
<b>7</b>	enter	PdEC	0.000	Decimal point for analogue input. Touch the key “SP+▲” to set the decimal point and confirm with "enter"	
<b>8</b>	enter	IS t	0000	Set the requested reading with the beginning of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>9</b>	enter	FS t	1000	Set the requested reading with the full scale of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>10</b>	enter	Out	UnOt	UnOt: servomotor control. Set the requested regulation by “SP+▲” and confirm with “enter“.	
<b>11</b>	enter	tInE	999.9	SERVOMOTOR TIME. Program the servomotor’s time in seconds and second’s decimals and confirm with “enter”	
<b>12</b>	enter	bAnO	10.0	DEAD BAND. Dead band, expressed in %, in which the servomotor is not piloted. Confirm with “enter”.	
<b>13</b>	enter	LISP	0 000	Lower limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
<b>14</b>	enter	LSSP	0 000	Upper limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
<b>15</b>	enter	OFFS	0 000	Using the number "OFFS" it is possible to correct the displayed temperature by adding or subtracting a constant written in the display "PV". To digit the number follow the procedure described in points 2 and 3	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
16	enter	Hb	0 100	If the “HB” option is installed on the instrument, set the desired value for the load current percentage. To digit the number follow the procedure described in points 2 and 3.	
17	enter	S.AL2	tEnP	Selection the kind of working Alarm2 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	
18	enter	AbA2	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	
19	enter	AL2	0 000	Alarm 2 value set up (if requested). To input the value see step 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
20	enter	ISA2	001	Alarm 2 hysteresis set up	
21	enter	C A2	nA	Possibility of inverting the second relay function nA = normally open nC = normally closed Set the requested regulation by “SP+ ▲ ” and confirm with “enter “.	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
22	enter	OUn	0 10	If analogue outputs are requested touch the key "SP+ ▲ " until the output required appears on the display and then confirm with "enter". 0 10 = output 0 ÷ 10 V 0 20 = output 0 ÷ 20 mA 4 20 = output 4 ÷ 20 mA	Pp 36
23	enter	tCOn	In	Control type: In = reverse function ( main relay = heating ) Dir = direct function To change this item use the "SP+ ▲ " key and confirm by "enter"	
	Exit	Read out	Set point		

### 2.4 INSTRUMENT WITH A VALVE CONTROL

The OUn function can be used only if the instrument has the analogue outputs. See paragraph "Analogue outputs".

The voltage heating regulation can be linked to 21 (+) and 23 (-) terminals, the current heating regulation can be linked to 22 (+) and 23 (-) terminals the voltage cooling regulation can be linked to 20 (+) and 23 (-) terminals.

Program the instrument following the table below; by "Exit" key it is possible to escape immediately from the menu.

For an heating control set "tCOn = In" and for a cooling control set "tCOn = dIr".

To set up control parameters see paragraph "Regulations".


For an automatic set point function, see paragraph "Ramp programming".

**Beware:** If out of range menu's item are programmed, they are proposed again at the maximum possible value.

To reset to factory default parameters you can see the paragraph "Default parameters".

# MPT390 M6

## 2.4.1 DIAGRAM MENU WITH A VALVE CONTROL



Search for the item to change, shown in the

upper display using key

The value to change is shown on the lower display. If you must change a number, use the key to increment the blinking digit,

and the key to shift the blinking digit, and if


you must select an item, use the key.

In either case use the key to confirm the input and go in the menu.

To exit the menu, press : the modified parameters will be stored.



# MPT390 M6



MPT390 M6

Table 6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See Page
1	enter	PASS	0 000	In this phase the instrument asks for the Password in order to save the data already programmed. The number memorized by the factory is 0, but any number between 0 and 9999 can be memorized by writing where CPAS appears ( next displayed item).	Pp 59
2	SP- ▶	PASS	0 0 00	Set Up Procedure. To digit the desired number touch the key " SP- ▶ " to move the flashing number to the right.	
3	SP+ ▲	PASS	0 1 00	Touch the key " SP+ ▲ " to increase the flashing number	
4	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
5	enter	SCAL	°C	Temperature scale: Choose the type of scale required. Set the requested scale (°C or °F) by "SP+ ▲" and confirm with "enter".	
6	enter	InP	PtE	Choose the type of sensor required. Touch the key "SP+ ▲ " until "SP" display appears on the chosen input: FECO = Fe/CO (0 ÷ 600 °C) (J) CrAL = Cr/Al (0 ÷ 1200 °C) (K) PtPr = Pt/Pt-Rh (0 ÷ 1710°C) (S) PtE = PT100 (-40 ÷ 800 °C) Ptr = PT100 (- 40.0 ÷ 200.0 °C) 0 10 = analogue input 0-10V 0 20 = analogue input 0-20mA 4 20 = analogue input 4-20mA To change this item use the "SP+ ▲ " key and confirm by "enter"	Pp 36

**MPT390 M6**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on SP display</b>	<b>NOTES</b>	<b>See Page</b>
<b>7</b>	enter	PdEC	0.000	Decimal point for analogue input. Touch the key “SP+ ▲” to set the decimal point and confirm with "enter"	
<b>8</b>	enter	IS t	0000	Set the requested reading with the beginning of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>9</b>	enter	FS t	1000	Set the requested reading with the full scale of the analogue input. To digit the number see 2 and 3 paragraphs.	Pp 36
<b>10</b>	enter	Out	OUn	OUn: analogue outputs for motorized valves. Set the requested regulation by “SP+ ▲” and confirm with “enter“.	
<b>11</b>	enter	LISP	0 000	Lower limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
<b>12</b>	enter	LSSP	0 000	Higher limit set-point. To digit the number follow the procedure described in points 2 and 3	Pp 35
<b>13</b>	enter	OFFS	0 000	Using the number "OFFS" it is possible to correct the displayed temperature by adding or subtracting a constant written in the display "PV". To digit the number follow the procedure described in points 2 and 3	
<b>14</b>	enter	Hb	0 100	If the “HB” option is installed on the instrument, set the desired value for the load current percentage. To digit the number follow the procedure described in points 2 and 3.	Pp 36
<b>15</b>	enter	S.AL1	tEnP	Selection the kind of working Alarm1 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the “SP+ ▲” key and confirm by “enter”	Pp 36

**MPT390 M6**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on SP display</b>	<b>NOTES</b>	<b>See Page</b>
<b>16</b>	enter	AbA1	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	Pp 36
<b>17</b>	enter	AL1	0 000	Alarm 1 value set up (if requested). To input the value see step 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
<b>18</b>	enter	ISA1	001	Alarm 1 hysteresis set up	Pp 36
<b>19</b>	enter	C A1	nA	Possibility of inverting the relay function nA = normally open nC = normally closed Set the requested regulation by “SP+ ▲ ” and confirm with “enter “.	Pp 36
<b>20</b>	enter	S.AL2	tEnP	Selection the kind of working Alarm2 tEnP = min or max absolute alarm value PEr = percentage alarm dELt = relative alarm at the set point SOGL = max absolute alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	
<b>21</b>	enter	AbA2	On	Minimum alarm enable. On: Minimum alarm relay is always enabled OFF: Minimum alarm relay is enabled after the first time the temperature reaches the alarm value To change this item use the “SP+ ▲ “ key and confirm by “enter”	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See Page
22	enter	AL2	0 000	Alarm 2 value set up (if requested). To input the value see step 2 and 3. An alarm can work as minimum alarm (if < set-point) or maximum alarm (if > set-point).	
23	enter	ISA2	001	Alarm 2 hysteresis set up	
24	enter	C A2	nA	Possibility of inverting the second relay function nA = normally open nC = normally closed Set the requested regulation by "SP+ ▲" and confirm with "enter".	
25	enter	OUA <sub>n</sub>	0 10	If analogue outputs are requested touch the key "SP+ ▲" until the output required appears on the display and then confirm with "enter". 0 10 = output 0 ÷ 10 V 0 20 = output 0 ÷ 20 mA 4 20 = output 4 ÷ 20 mA	
26	enter	tCO <sub>n</sub>	In	Control type: In = reverse function ( main relay = heating ) DIr = direct function To change this item use the "SP+ ▲" key and confirm by "enter"	
27	enter	bAnr	10.0	Touch "enter" the key until the item bAnr appears = cooling dead band (see paragraph)	
	Exit	Read out	Set point		

### 2.5 SET POINT MODIFICATIONS

Using the keys on the panel "SP+ ▲" and "SP- ▼" it is possible to increase or decrease the number corresponding to the set point without having to use the programming menu. For a fast change keep pressed the key. In order to block the movement of the set point between two limits, programme the menu where "LISP" appears for the lower limit and "LSSP" for the upper limit. These limits don't interfere with the ramp programs.

## **MPT390 M6**

### **2.6 HB ANALOGUE INPUT**

The instruments of the "MPT/390" series can be requested with the "HB" function, that is continuous load control.

In this case it is necessary to prepare, as in the diagram, the link to a TA/1 of the correct range in line with the current which flows in the load. It is advisable the use of an ammeter-type transformer for the control of the base current, and it is better to decouple the load voltage with the "GND" of the instrument.

The instrument, when power is delivered to the load, checks the effective current through the circuit. The load interrupt condition will be shown by the spy light on the front of the instrument, and, if requested, from the alarm 2 relay. This signal does not block in any way the functioning of the instrument which continues the heat regulation and alarm 2 controls (if requested).

In the case that the instrument finds the load break during "self-tuning", there appears on the display the message "Err 3" and the principal relay becomes disconnected ( see paragraph " self-tuning function").

It is possible to monitor the current into the load by means of the "HB" menu item. The "HB" value can be set in the range 0÷100 and means the value of the current percentage in the load below which the alarm HB will be set. A 0 value in the "HB" item disables the alarm setting.

### **2.7 ANALOGUE INPUTS**

The instruments of the "MPT/390" series works with these analogue inputs:

- Current input " 4 ÷ 20 mA "
- Current input " 0 ÷ 20 mA "
- Voltage input " 0 ÷ 10 V "

For each inputs it is possible to set any reading value in the range: -999 ÷ 2000.

To set these inputs the " is t " and " fs t " items will be used for the beginning scale and full scale of the requested input. The programmed value could be corrected with " OFFS " item of menu. With the analogue output it is possible to set also the decimal point (PDEC). The voltage or current input must be linked to 25 terminal ( positive current input ) or 24 ( positive voltage input ) and 28 (gnd).

### **2.8 FUNCTION OFF-SET (OFFS)**

If during the normal functioning of the heat regulator you see a constant difference between the value measured by the sensor or analogue input and the real value, it is sufficient to write the difference in the "OFFS" function as in the diagram below..

ATTENTION: the offset must be within -19.9 e 19.9 °C in the scale Pt r (-40.0 ÷ 200.0 °C) otherwise between -199 e 199 °C for all the other scales and is added to the temperature measured by the sensor.

### **2.9 SET UP AL1 and AL2**

The thermoregulator MPT/390 offers the possibility to use two programmable alarms. This alarm can work with the following set up:

## MPT390 M6

**S.AL1 or SAL2= tEnP.** The alarm value (AL1 or AL2) is set up with the absolute value. If AL1 or AL2 < SP the alarm works when the temperature goes under the AL value (it can be enabled at the first switching on if AbA1/AbA2= on or after that the temperature has come to the alarm value for the first time if AbA1/AbA2=off); if AL1 or AL2 > SP the alarm works when the temperature goes over the AL value.

**S.AL1 or SAL2= Per.** The alarm value (AL1 or AL2) is set up with the percentage value based on the set-point (from 0 to  $\pm 100.0\%$  of the set point). If AL1 or AL2 is set up between  $-0.1\%$  and  $-100.0\%$  the alarm works when the temperature goes under the SP value – SP percentage (it can be enabled at the first switching on if AbA1/AbA2 = on or after that the temperature has come to the alarm value for the first time if AbA1/AbA2 = off); if AL1 or AL2 is set up between  $+0.1\%$  and  $+100.0\%$  the alarm works when the temperature goes over the SP value + SP percentage.

**S.AL1 or S.AL2 = dELt.** The alarm value (AL1 or AL2) is set up in  $^{\circ}\text{C}$  offset about the set point. If AL1 or AL2 is set up between  $-0$  and  $- \text{F.S. } ^{\circ}\text{C}$  the alarm works when the temperature goes under the SP value – set up offset (it can be enabled at the first switching on if AbA1/AbA2 = on or after that the temperature has come to the alarm value for the first time if AbA1/AbA2 = off); if AL1 or AL2 is set up between  $+ 0$  and  $+ \text{F.S. } ^{\circ}\text{C}$  the alarm works when the temperature goes over the SP value + set up offset.

**S.AL1 or S.AL2 = SOGL.** The alarm value (AL1 or AL2) is set up in absolute value between 0 and F.S. and the alarm works when the processing temperature goes over the AL1 or AL2 set up temperature.

The alarm contact is configurable as “normally open” or as “normally closed” by the “CA1/ CA2” item while the alarm relay hysteresis is programmable from 0 to F.S. value (digits/degrees) by the “ISA1/ISA2” item.

The led on the frontal does not follow the contact programming but it follows the alarm function.

The described functioning is active for alarm 1 just at the moment when “Out” = “rISC” or “Out” = “OUAn”. If “Out” = “rIrA” or “Out” = “UnOt” the alarm 1 respectively works for the cooling or for the servomotor function so the alarm 1 output changes the type of functioning depending on the requested regulation.



### 3.0 ANALOGUE OUTPUT (option)

The thermoregulator MPT/390 offers the possibility to supply the standard ( OAP ) or opto isolated ( OAC ) analogue outputs. Both options are able to supply 3 types of outputs: “  $0 \div 20 \text{ mA}$  “, “  $4 \div 20 \text{ mA}$  “, “  $0 \div 10 \text{ V}$  “ to transmit the read out or to control the motorized valves.

## MPT390 M6

Table 7

<b>Analogue outputs</b>	0÷10 V - 0÷ 20 mA - 4÷20 mA
<b>Max load for current output</b>	300 Ω
<b>Min load for voltage output</b>	1KΩ
<b>Max voltage output</b>	10 V
<b>Max current output</b>	20 mA
<b>Resolution</b>	12 bits

### 3.1 ANALOGUE OUTPUT FOR MOTORIZED VALVE

To use analogue output for motorized valve it is necessary to set the voice “ Out “ = “ OUA n “ ( see paragraph “ Instrument with a valve control” ).

There are two outputs for cooling and heating regulations.

The heating regulation can be selected in voltage ( 0 ÷ 10 V: terminals 21 and 23 - gnd-) or current ( 0/4 ÷ 20 mA: terminals 22 and 23 -gnd- ) while the cooling regulation can be only in voltage (0 ÷ 10 V: terminals 20 and 23 -gnd-).

The analogue outputs will be calculate every PID cycle ( C I C L ). For other information see INSTRUMENT WITH A VALVE CONTROL paragraph.

### 3.2 ANALOGUE OUTPUT FOR READOUT

If the instrument has the analogue output (option OAP or OAC) and the voice “Out “ is selected as “rISC “, “rIrA “, or “UnOt “, the analogue output is proportional to the readout value.

The output can be selected in voltage or current mode. The terminals for voltage output are 21 and 23 (gnd), while the terminals for current output are 22 and 23 (gnd). The next table shows the couplings of the readout with the analogue outputs.

Table 8

<b>ANALOGUE OUTPUT RANGE</b>	<b>BEGINNING SCALE OF ANALOGUE OUTPUT</b>	<b>FULL SCALE OF ANALOGUE OUTPUT</b>
<b>0÷10V for Pt r</b>	0V ≡ -40.0 °C	10V ≡ 200,0 °C
<b>0÷10V for Pt E</b>	0V ≡ 0 °C	10V ≡ 800 °C
<b>0÷10V for FE-CO</b>	0V ≡ 0 °C	10V ≡ 600 °C
<b>0÷10V for Cr-Al</b>	0V ≡ 0 °C	10V ≡ 1200 °C
<b>0÷10V for PtPr</b>	0V ≡ 0 °C	10V ≡ 1710 °C
<b>0÷10V for analogue input</b>	0V ≡ IS t	10V ≡ FS t
<b>0÷20 mA for Pt r</b>	0 mA ≡ -40.0 °C	20 mA ≡ 200,0 °C
<b>0÷20 mA for Pt E</b>	0 mA ≡ 0 °C	20 mA ≡ 800 °C
<b>0÷20 mA for FE-CO</b>	0 mA ≡ 0 °C	20 mA ≡ 600 °C
<b>0÷20 mA for Cr-Al</b>	0 mA ≡ 0 °C	20 mA ≡ 1200 °C
<b>0÷20 mA for PtPr</b>	0 mA ≡ 0 °C	20 mA ≡ 1710 °C
<b>0÷20mA for analogue input</b>	0 mA ≡ IS t	20 mA ≡ FS t



## MPT390 M6

<b>4÷20 mA for Pt r</b>	4 mA $\equiv$ -40.0 °C	20 mA $\equiv$ 200,0 °C
<b>4÷20 mA for Pt E</b>	4 mA $\equiv$ 0 °C	20 mA $\equiv$ 800 °C
<b>4÷20 mA for FE-CO</b>	4 mA $\equiv$ 0 °C	20 mA $\equiv$ 600 °C
<b>4÷20 mA for Cr-Al</b>	4 mA $\equiv$ 0 °C	20 mA $\equiv$ 1200 °C
<b>4÷20 mA for PtPr</b>	4 mA $\equiv$ 0 °C	20 mA $\equiv$ 1710 °C
<b>4÷20 mA for analogue input</b>	4 mA $\equiv$ IS t	20 mA $\equiv$ FS t

### 4.0 REGULATIONS

The thermoregulator MPT/390 allows the possibility to control the temperature in 3 different ways:

1. Automatic regulation (Pot = cont)
2. Manual regulation (Pot = man)
3. Disabled regulation (Pot = OFF)

In the first case ( automatic control ) the instrument works with ON-OFF or Pid controls in accordance with item "Cont" ( see PID TYPE REGULATION and ON-OFF TYPE REGULATION paragraphs ).

In the second case ( manual control ) the instrument works with a value of power defined from the user. This value appears on SP display and it is possible to modify it by "SP+ ▲ " and "SP- ▶ " items. Set on the menu the necessary cycle time.

In the third case ( disabled control ) the instrument disables all outputs and "OFF" appears on the SP display.

In the second and third cases it is not possible to use the ramp programs.

### 4.1 PID TYPE REGULATION

The PID regulation, if selected, allows the direct programming of the following keyboard parameters:

- - cycle time (CICL)  $1 \div 200$  sec

**Attention:** if the cycle time =  $1 \div 200$  sec only the static output works, if the cycle time =  $10 \div 200$  sec the static output works coupled with the main relay.

- - proportional band (ProP)  $0 \div$  F.S. °C/°F
- - time req. for integrative action (IntE)  $0 \div 6000$  sec
- - time req. for derivative action (dErI)  $0 \div 600$  sec
- - constant Cutback (CUtb) (see paragraph)  $0 \div$  F.S. °C/°F

A quick way which guarantees correct operation is automatic parameter calculation by the machine itself using the "SELF-TUNING" function (see paragraph).

The enumerated parameters are valid for the heating control and for the cooling control too. If the instrument is used for a cooling control, a parameter is added and it defines the dead band (bAnr) in which is programmed the % of power under which the control is cancelled.

## MPT390 M6

### 4.1.1 CUTBACK FUNCTION

With the function "CUTBACK" it is possible to reduce the temperature overshoot that can occur in certain processes. The number "Cutb" that can be programmed is expressed in °C/°F in the range 0÷F.S. of the chosen input. The insertion of this function avoids overshoot.

There are two methods to programme this function:

1) AUTOMATIC MODE: launch the self tuning command which calculates the constants P, I, D, and CUTBACK.

2) MANUAL MODE: Check manually how many degrees, during the first power on, are above the set-point (regulation made with parameters P - I - D - in line with the controlled thermal system ). Write this data in the "CUTBACK" function. To exclude the function described it is sufficient to write "0" in "Cutb" menu item.

**Table 9**

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
1	enter	PASS	0 000	Number of Password	Pp 59
2	SP- ▶	PASS	0 0 00	Set Up Procedure. To input the desired number press the key " SP- ▶ " to move the flashing number to the right.	
3	SP+ ▲	PASS	0 1 00	Touch the key " SP+ ▲ " to increase the flashing number	
4	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
	enter			Press the key "enter" until to reach the desired menu item "Cont"	
28	enter	Cont	Pid	Selecting Pid control the instrument will allow the following items	Pp 39
29	enter	CICL	0 000	Set up the cycle time required for the control. Under 10 sec. only the static output is guided, over 10 sec., the static output plus relay. To input the number follow the procedure described in points 2 and 3	
30	enter	ProP	0 000	Set up of the proportional band	

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES	See page
31	enter	IntE	0 000	Set up of the integrative constant	
32	enter	dErI	0 000	Set up of the derivative constant	
33	enter	CUtb	0 000	Set up of the temperature overshoot. For all these set ups follow the description of points 2 and 3	Pp 40
34	enter	SoSt	0 000	Set up of the temperature value under which the load becomes 30% guided. For all these set ups follow the description of points 2 and 3	Pp 43
27	enter	bAnr	0000	Cooling dead band. Only if Out = rIrA or Out = OUA If you control Pid, put in the % of power under which the cooling control is cancelled.	
35	enter	SoSt	0 001	Set up the temperature value under which the load becomes 30% guided	
	exit	Read out	Set point		

### 4.1.2 SELF-TUNING FUNCTION (setu)

The self-tuning function calculates the parameters of the Pid regulation (proportional band, integrative time, derivative time and CUTBACK function) to obtain a temperature control that is as precise as possible. The calculations of the self tuning function, if set-up in the programming phase, can be seen on the flashing "PV" display. The calculation of the parameters consists of a heating cycle that the thermoregulator must follow with the working set point taking account of the thermal system installation. To use the self-tuning function it is necessary to remember that:

1. the self-tuning action can provoke an overshoot and depending on the thermal system used; the test can last from a few minutes to several hours.
2. eventual "soft-start" programming is not considered but comes into use at the end of self-tuning.
3. for a correct calculation of the parameters it is better from the users point of view to begin the self tuning procedure at room temperature and as far away as possible from the set point.
4. There exist certain conditions in which is not possible to finalize the parameter calculations. In these situations the instrument blocks the "self-tuning" action and displays an error code that defines the type of anomaly found:
  - a) temperature  $\geq$  at set-point (Err 1)
  - b) sensor interrupted or condition of over range (Err 2)
  - c) load interrupted (if option HB requested) (Err 3)

## MPT390 M6

d) set-point too near to initial temperature (Err 4) ( initial temperature less than  $-10\%$  of the Set-Point )

In these conditions the instrument follows the abort function, showing on the "PV" display the message relating to the displayed error and deactivating the actuators. The instrument will work again only when the operator press the "enter" key and corrects the anomaly.

- The self tuning function is, however, annullable at any moment, it being sufficient to touch "enter", inserting the password number and when the "abort" signal appears, press the "SP+▲" key to make "on" appear and then confirm with "enter".
- After the self tuning phase it is necessary, to set up the cycle time (if the programming control = "PID" and cycle time = 0 the instrument works like a thermometer ).

### 4.2 ON-OFF TYPE REGULATION

The ON-OFF regulation, if selected, allows hysteresis programming. The hysteresis must be set up in "degrees" relative to the set-point and the variation should be symmetric in relation to the desired temperature.

EXAMPLE: set-point =  $300\text{ }^{\circ}\text{C}$

IStE =  $10\text{ }^{\circ}\text{C}$

the main working relay (RL 1) is on until  $310\text{ }^{\circ}\text{C}$ , and it will be on again at  $290\text{ }^{\circ}\text{C}$ .

You can set up the values in degrees from 1 (0,1 for the Ptr scale) to F.S. as requested.

The On-OFF control, with heating-cooling regulation, inserts a new item to define a dead band (bAnr). The functioning of this control is described in the following figure.




Table 10

ref.	touch key	appears on PV display	appears on SP display	NOTES	See Page
1	enter	PASS	0 000	Number of Password	Pp 59
2	enter	CPAS	0 000	Number of the access key to the programming of the instrument. The number written in this phase will be requested at "PASS". To digit the number follow the procedure described in points 2 and 3.	Pp 59
	enter			Press the "enter" key until to reach the desired "Cont" menu item	
38	enter	COnt	OnOF	Selecting On-OFF control the instrument will allow the following items	Pp 42
39	enter	IStE	0003	Set up hysteresis.	Pp 42
27	enter	bAnr	0000	Cooling dead band. Only if $OU_t = rIrA$ or $OU_t = OUA_n$ . If you have an On-Off control put the band in °C in which will be inhibited the heating and cooling control.	
35	enter	SoSt	0 000	Set up the temperature value under which the load becomes 30% guided	Pp 43
	Exit	Read out	Set point		

### 4.3 SOFT-START FUNCTION (sost)

The function soft-start guarantees a "cold" departure of the thermoregulator with a command of the heating elements not above 30% of maximum power, in the range of temperature set up at the "SOS<sub>t</sub>" command. The value, which can be programmed, is between 0÷F.S. °C/°F, and as a consequence, a higher initial temperature automatically excludes the function. After having set up this system please put off and then start up again the instrument to set working this function.

Also with the "On-Off" regulation it is possible to use the "soft-start" option; this is used with a fixed cycle time of 10 sec.

## MPT390 M6

If the type of control is set up in direct function ("tcon = dir") the soft start function is not available.

After setting up the programme, the soft-start function is, however, annullable at any moment with this procedure :

1. to press "enter", inserting the password number
2. when the "abort" signal appears, press the "SP+ ▲ " key to make "on" appear and then confirm with " enter ".

The soft-start function, if set up, is shown by both "PV" and "SP" flashing on the display.



### 5.0 RAMP SET UP

The MPT/390 instrument can execute automatic cycles with steps. The ramp set up allows the automatic set point variation while the base regulator functions are programmed in the main menu (see "installation notes"). It is possible to set up 3 programs of 8 steps each (linking together). Settings are performed through menu item **PrAn = OFF**. For each step it is defined the final temperature and its duration up to 99 hours and 99 minutes.

It's not possible to set up the first step of each program with zero duration.

The "Pot" menu item is not available when ramps are working.

There are some available options:

**RIPR:** program repetition. Selecting this item at "on" you qualify the selected programs to be repeated to infinity. This selection excludes the following "COFR" (ramp control at last step).

**COFR:** ramp control at last step. This menu's item can be selected in "STOP", if is requested that the thermoregulator, ended the programmed cycle, turns off the load, or can be selected in "REG", if is requested that the thermoregulator, ended the programmed cycle, controls with last set-point.

**DESP:** delay starting program. This menu's item allows to set up a delay time at the beginning of the selected programs. The maximum time that can be set up is 99 hours and 99 minutes. During the delay time the instrument presents the flashing led RP. Pressing the "START/STOP" + "enter" keys the instrument resets the actual time delay and immediately enables the ramp to execute. To read the residual delay time you must press the "SP+ ▲ " key . In this case you can read on the displays PV and SP the following information:

**trES** (residual time)

**01.23** (1 hour and 23 minutes)

To reset to factory default parameters you can see the paragraph "Default parameters".

## MPT390 M6


### 5.1 KEY FUNCTIONS

“**RAMP**” key: access to the “Ramps’ programs”. The “ramp” key can be disabled by the menu item “Abtr” (Abtr=OFF).


**Attention: it is not possible to change the current step.**

“**EXIT**” key : to get out of the menu is sufficient to press the “Exit” key; the instrument goes in process saving the set ups executed till then.

“**START/STOP**” keys: during a ramp program, if the “STOP” key is pressed (STOP function), the instrument turns off the heating and, the SP display and the led on blink. When you press the “START” key , the instrument starts again the execution of the program from where it had been suspended.



5.2 DIAGRAM RAMP MENU



Touch the **Ramp** Key for the ramp program  
 Search for the item to change, shown in the upper display using key **Enter**  
 The value to change is shown on the lower display. If you must change a number, use the **SP+** key to increment the blinking digit, and the **SP-** key to shift the blinking digit, and if you must select an item, use the **SP+** key.  
 In either case use the **Enter** key to confirm the input and go in the menù.  
 To exit the menù, press **Exit** : the modified parameters will be stored.



# MPT390 M6

## Table 11

ref.	touch key	appears on PV display	appears on SP display	NOTES
50	Ramp	PrAn	OFF	<p>Program number:</p> <p><b>OFF:</b> no program</p> <p><b>1:</b> program n°1</p> <p><b>2:</b> program n°2</p> <p><b>3:</b> program n°3</p> <p><b>1.2:</b> program n°1 + n°2</p> <p><b>1.2.3:</b> program n°1 + n°2 + n°3</p> <p>To change this set up press the “SP+ ▲” key and confirm with “enter”</p>
51	enter	PASr	0000	Password number for ramp program
52	enter	CPAr	0000	Password change for ramp program
53	enter	rIPr	OFF	<p>Repetition selected programs</p> <p><b>OFF:</b> executes only one time the selected programs</p> <p><b>On:</b> repeats to infinity the selected programs</p> <p>To change this set up press the “SP+ ▲” key and confirm with “enter”</p>
54	enter	COFr	StOP	<p>Ramp control at last step (only if rIPr = OFF)</p> <p><b>StOP:</b> ended the set up program the instrument goes in stop</p> <p><b>rEG:</b> ended the set up program the instrument controls on last set point.</p> <p>To change this set up press the “SP+ ▲” key and confirm with “enter”</p>
55	enter	dESP	02.00	<p>Delay time before to start the program.</p> <p>Set up the time in hours and minutes relative at the requested delay pressing the “SP+ ▲” + “SP- ▸”keys</p>
56	enter	AbtS	OFF	<p>Enabling “START/STOP” keys:</p> <p><b>OFF:</b> disabled keys</p> <p><b>On:</b> enabled keys</p> <p>To change this set up press the “SP+ ▲” key and confirm with “enter”</p>

## MPT390 M6

ref.	touch key	appears on PV display	appears on SP display	NOTES
57	enter	1dU1	00.30	Program n°1, step n°1 duration. Input time in hours and minutes for the step using “SP+ ▲ “ and “SP- ▶” keys. Attention: it is not possible to set at zero the first duration.
58	enter	1tF1	0020	Program n°1, final temperature for step n°1. Input the desired temperature using the “SP+ ▲ “ key to increase the blinking digit and the “SP- ▶” key to shift the blinking digit
59	enter	1dU2	00.50	The program set up goes on with the set up of the second step of the first program. At the end of the 8 <sup>th</sup> step the menu shows the 8 steps of the second program and then the 8 steps of the third program.

The instrument performs the program selected in the PrAn item of the menu (if PrAn=OFF the instrument works normally). The program starts with the first step. At the end of the program and if rIPr=OFF the instrument shuts down the heating control, the last set point will flash together with the led “on” if COFr=StOP or, vice versa the instrument controls on last set-point if COFr=rEG.

If rIPr=On the instrument starts again from the beginning and repeats to infinity the selected programs. If COFr=StOP at the end of selected program we have a “STOP” function and the instrument shuts down the control and the SP display and led “on” flash. The “STOP” function of the end of the program is also memorized at power off condition.

After a “STOP” condition caused by the end of the program, the instrument will work again if one of the following conditions happen:

- 1 no ramp program set up (PrAn=OFF). The instrument controls on last set-point.
- 2 new ramp program. Selecting in “PrAn” item one available programs, the instrument goes on execution starting from the first programmed step with the same initial measured temperature at that time.
- 3 with “START/STOP” key press the instrument start again from the ramp program that were in execution, starting from the first programmed step with the same initial measured temperature at that time.

When a step program is in progress, the upper (PV) display shows the process temperature, and the lower (SP) display shows the dynamic set point of the regulator. Besides the led “RP” blinking for the duration of the chosen program. While the step program is running, it is possible to see the residual time of the step in progress and

## MPT390 M6

its final temperature by pressing the “SP+ ▲” key: the information will be displayed as:

**trES** (residual time)  
**01.23** (1 hour and 23 minutes)


**tFin** (final temperature)  
**0100** (100 °C)

At the end of the current step, if the temperature is not within 3 grades respect to the computed set point, the regulator waits for this condition before executing the next step.

After a “STOP” because “START/STOP” key is pressed, the instrument shuts down the control and SP display and led “on” flash. The STOP function is also memorized at the power off of the instrument. The instrument after a STOP phase will work again if one of the following conditions happen:


- 1 no ramp program set up (PrAn=OFF). The instrument controls on last set-point.
- 2 new ramp program. Selecting in “PrAn” item one available programs, the instrument goes on execution starting from the first programmed step with the same initial measured temperature at that time.
- 3 with “START/STOP” keys press : the instrument controls on suspended ramp ( see fig. 2 ). A ramp is considered finished if the temperature is within  $\pm 3^\circ$  of the final programmed temperature.

If during the functioning the instrument is powered off, the current step is stored and at the next power on this stored step is reload. If the temperature, during power off, exits from the range of the stored step, at the power on the instrument will continue as shown in the figures 3, 4, 5, 6.



**Fig 3**

**Fig 4**



**Fig 5**

**Fig 6**

## MPT390 M6



### 6.0 SERIAL OUTPUT

MPT/390 models can communicate with an host computer along a standard or optoisolated RS232, RS422, RS485 serial.

#### Bi-directional serial output

By the serial output it is possible to read out and write all parameters of the instrument. It is possible to connect up to 31 instruments (with RS485). All messages are sent and received by the serial output by an ASCII protocol.

**Table 12**

<b>SERIAL CHARACTERISTICS</b>	
<b>baud rate</b>	9600 4800 2400 1200 (programmable by the keyboard)
<b>start bit</b>	1 bit
<b>Length</b>	8 bit
<b>Stop</b>	1 bit
<b>Parity</b>	No

The MPT390 M6 model with RS422 or RS485 the wiring diagram is shown in fig B. The MPT390 M6 model with RS232 the wiring diagram is shown in fig A. To program the address and the baud rate see the following table.

**Table 13**

<b>ref.</b>	<b>touch key</b>	<b>appears on PV display</b>	<b>appears on Sp display</b>	<b>NOTE</b>	<b>See page</b>
<b>1</b>	enter			Press the "enter" key to get into the programming menu	
	enter	PASS	0 000	Digit the password number	Pp 59
	enter	PASS	0 0 00	Change the Password number and confirm with "enter"	
	enter			Press the "enter" key until you see the "Addr" message on the "PV" display	
<b>36</b>	enter	Addr	0 000	Write the address code	Pp 50
<b>37</b>	enter	bAUd	9600	Press the "SP+ ▲" key until you see the right baud rate (1200, 2400, 4800 o 9600). Confirm by "enter"	Pp 50

## MPT390 M6




Figure A




Figure B

### 6.1 DATA READING FROM HOST TO INSTRUMENT MPT

Transmission string set-up.

EOT GID GID UID UID C1 C2 ENQ

EOT = EOT from host indicates the start of transmission string

GID = ASCII code for the tenths of the instrument address to transmit twice consecutively

UID = ASCII code for the units of the instrument address to transmit twice consecutively

C1 C2 = mnemonic ASCII code for command to execute. (see paragraph "COMMAND CODES")

EXAMPLE: data transmission string from host to MPT with address "01" for request of Set-Point (SP)

EOT 0 0 1 1 S P ENQ  
04 30 30 31 31 53 50 05 cod. ASCII

## MPT390 M6

The instrument, from the moment in which it receives the first string code transmitted by the host, leaves 400 mSec. during which it waits for the end of the transmission operation. When the 400 mSec. operation finishes, or when the data reception is completed, the instrument, depending on the information received, can behave in the following four ways:

- 1) If the data string received presents errors which do not allow address identification then the instrument cannot reply and rejects the information received.
- 2) The string has a correct address code but it detects other errors; in this case the instrument transmits the ASCII code: NACK (not understood) and rejects the information received.
- 3) The received data string is totally completed, in this case the instrument transmits the data requested in ASCII format (see paragraph "DATA TRANSMISSION FROM MPT TO HOST").
- 4) When the complete message is not received before "timeout" (400 mSec), the instrument rejects the information received and it is ready to receive a new message.

### 6.2 DATA TRANSMISSION FROM MPT TO HOST

Transmission string configuration

STX   C1 C2   D1 . . . . D6   ETX   BCC

STX = start of text

C1 C2 = mnemonic code ASCII relative to command to execute ( see paragraph "COMMAND CODES")

D1 ÷D6 = Numbers displayed, including negative sign, ">", decimal points (if it is present ) and blank or zero for not significant digits ( the transmitted digits must always be 6)

**ATTENTION:** the data must always be "supported" on the right and in any case the significant numbers cannot be more than five. In the case of positive numbers the sign "+" must not be transmitted.

**EXAMPLE:** the number -5.6 can be written in two ways

1) blank	blank	-	5	.	6
20	20	2D	35	2E	36
2) -	0	0	5	.	6
2D	30	30	35	2E	36

ETX = End of text

BCC = Checksum, obtained using EXCLUSIVE OR, of the transmitted string excluding the code "STX" comprising "ETX" in the indicated order.

## MPT390 M6

$$BCC = C1 + C2 + D1 + D2 + D3 + D4 + D5 + D6 + ETX$$

EXAMPLE: data string from MPT to host in response to example above.

STX	S	P	blank	blank	0	1	0	0	ETX	BC
02	53	50	20	20	30	31	30	30	03	01 cod.ascii

The MPT after having transmitted the string with the data requested from the host-computer waits the reply confirming the result of the transmission executed.

- 1) The host-computer replies in ASCII: NACK (not understood). The MPT transmits again the data string.
- 2) The host-computer does not reply. In this case the instrument waits the next EOT on the network to set up the next communication.
- 3) The host-computer replies in ASCII: ACK (understood). The instrument waits new commands.

### 6.3 DATA WRITING FROM HOST TO MPT

Set up of transmission string

EOT GID GID UID UID STX C1 C2 D1... D6 ETX BCC

EOT = EOT from host indicates the start of transmission string

GID = ASCII code for the tenths of the instrument address to transmit twice consecutively

UID = ASCII code for the units of the instrument address to transmit twice consecutively

C1 C2 = mnemonic ASCII code for command to execute (see paragraph "COMMAND CODES")

D1 ÷ D6 = Digits displayed. The same rules are valid as those described in the paragraph " data transmission from MPT to host"

BCC = Checksum, obtained using EXCLUSIVE OR, of the transmitted string excluding the code "STX" comprising "ETX" in the order indicated

$$BCC = C1 + C2 + D1 + D2 + D3 + D4 + D5 + D6 + ETX$$

EXAMPLE: string for writing data from host to MPT with "01". address.

EOT	0	0	1	1	STX	S	P	blank	blank	0	1	0	0	ETX	BCC
04	30	30	31	31	02	53	50	20	20	30	31	30	30	03	08

The instrument, from the moment in which it receives the first code of the data string transmitted by the host, makes to start 400 mSec during which it waits for the

## MPT390 M6

transmission operation to be completed. When the 400 mSec. operation finishes, or when the data reception is completed, the instrument, depending on the information received, can behave in four different ways:

- 1) If the data string received presents errors which do not allow address identification then the instrument cannot reply and rejects the information received.
- 2) The string has a correct address code but detects other errors; in this case the instrument transmits the ASCII code: NACK (not understood) and rejects the information received.
- 3) The received data string is totally completed, in which case the instrument writes the information memorized and transmits the code ASCII=ACK (understood)
- 4) When the complete message is not received before "timeout" (400 mSec.), the instrument rejects the information received and is ready to receive a new message.

### 6.4 COMMAND CODES

The codes of the variables used for the MPT instrument programming, are listed into the following table. Not all the parameters allow the writing from host, in this case the instrument does not work and replies "NACK".

**Table 14**

<b>COMMAND CODES</b>	<b>COMMAND DESCRIPTION</b>	<b>ALLOWED SET-UP</b>	<b>TYPE OF CODE</b>
<b>SC</b>	Scale (SCAL)	read/write	hexadecimal 0 = °C 1 = °F
<b>OU</b>	Output (OUt)	read/write	hexadecimal 0 = RISC 1 = RIRA 2 = VMOT 3 = OA
<b>CO</b>	Control (Cont)	read/write	hexadecimal 0 = on-off 1 = Pid



**MPT390 M6**

<b>COMMAND CODES</b>	<b>COMMAND DESCRIPTION</b>	<b>ALLOWED SET-UP</b>	<b>TYPE OF CODE</b>
<b>IN</b>	Input	read/write	hexadecimal 0 = Fe/Co 1 = Cr/AL 2 = Pt/Pt-Rh 3 = PT100E: 0÷800°C 4 = PT100r:-40.0÷200,0°C 5 = 0 ÷ 10V 6 = 0 ÷ 20 mA 7 = 4 ÷ 20 mA
<b>OA</b>	Selection analogue outputs	read/write	hexadecimal 0 = 0.10 (V) 1 = 0.20 (mA) 2 = 4.20 (mA)
<b>PD</b>	Decimal point	read/write	hexadecimal 0 = no point 1 = 199.9 2 = 19.99 3 = 1.999
<b>IT</b>	Beginning scale (IS T)	read/write	ASCII -200÷2000
<b>FT</b>	End of scale (FS T)	read/write	ASCII -200÷2000
<b>B1</b> <b>B2</b>	Alarm 1 enable (AbA1) Alarm 2 enable (AbA2)	read/write	hexadecimal 0 = off 1 = on
<b>CI</b>	Cycle (CICL)	read/write	ASCII 0÷200
<b>OF</b>	Offset (OFFS)	read/write	ASCII 0÷F.S.
<b>A1</b> <b>A2</b>	Alarm 1 (AL1) Alarm 2 (AL2)	read/write	ASCII 0÷F.S.
<b>C1</b> <b>C2</b>	Relay function Al.1 (C A1) Relay function Al.2 (C A2)	read/write	hexadecimal 0 = normally open 1 = normally closed
<b>I1</b> <b>I2</b>	Hy AL1 (ISA1) Hy AL2 (ISA2)	read/write	ASCII 0÷F.S.

**MPT390 M6**


<b>COMMAND CODES</b>	<b>COMMAND DESCRIPTION</b>	<b>ALLOWED SET-UP</b>	<b>TYPE OF CODE</b>
<b>T1</b> <b>T2</b>	Selection alarm 1 Selection alarm 2	read/write	hexadecimal 0 = tEMP 1 = dELt 2 = PEr 3 = SOGL
<b>TV</b>	Valve time	read/write	ASCII 0÷999.9
<b>BM</b>	Dead band	read/write	ASCII 0÷100.0
<b>BR</b>	Cooling dead band	read/write	ASCII 0÷100.0
<b>KP</b>	Proportional band (PrOP)	read/write	ASCII 0÷F.S.
<b>KI</b>	Integrative action (IntE)	read/write	ASCII 0÷6000Sec.
<b>KD</b>	Derivative action(dErI)	read/write	ASCII 0÷600Sec.
<b>SP</b>	Set-point	read/write	ASCII 0 ÷ F.S.
<b>HB</b>	HB (HB)	read/write	ASCII 0 ÷ F.S.
<b>LI</b>	Lower limit set-point (LISP)	read/write	ASCII 0 ÷ F.S.
<b>LS</b>	Higher limit set-point (LSSP)	read/write	ASCII 0÷F.S.
<b>SS</b>	Soft-start (SOSSt)	read/write	ASCII 0÷100°C/°F
<b>CB</b>	Cutback (cutb)	read/write	ASCII 0÷F.S.
<b>TE</b>	Read out	only write	ASCII 0÷F.S.
<b>IS</b>	Histeresis (Hy)	read/write	ASCII 0÷F.S.
<b>SW</b>	Status word	read/write	Hexadecimal (see paragr.)
<b>SR</b>	Start/stop ramp	read/write	hexadecimal 0 = ramp on 1= ramp in stop
<b>PR</b>	Program ramp	read/write	0=OFF 1=1 2=2 3=3 4=1+2 5=1+2+3
<b>FR</b>	End of ramp control (COFR)	read/write	hexadecimal 0 = OFF 1 = REG

## MPT390 M6

COMMAND CODES	COMMAND DESCRIPTION	ALLOWED SET-UP	TYPE OF CODE
TR	Disabled ramp key	read/write	hexadecimal 0 = OFF 1 = On
RP	Program repetition (RIPR)	read/write	hexadecimal 0 = OFF 1 = On
IP	Delay starting program	read/write	ASCII HH.MM
RX	Modify ramp parameters	read/write	ASCII 1÷3
X1-X8	Time step	read/write	ASCII (see paragraph)
Y1-Y8	Final temperature	read/write	ASCII (see paragraph)
PP	% of power	Only read	ASCII -100 ÷ +100
TC	Control type	read/write	hexadecimal 0 = reverse 1 = direct
PO	Power	read/write	hexadecimal 0 = automatic regulation 1 = manual regulation 2 = disabled regulation
PM	Manual power	read/write	ASCII -100.0 ÷ +100.0

### 6.5 STATUS WORD

The status word must be transmitted in a 4 digit hexadecimal format.



### 6.6 TRASMISSION OF HEXADECIMAL VALUES

Some values must be transmitted in a 4 digit hexadecimal format. In that case the protocol string must be preceded by the ASCII character ">".

**EXAMPLE:** for CONT=PID the data will be: blank >0001

## MPT390 M6

### EXAMPLE OF READING STATUS WORD

HOST:

```
EOT  0  0  1  1  S  W  ENQ
04  30  30  31  31  53  57  05
```

MPT INSTRUMENT:

```
STX  S  W  blank  >  0  0  0  4  ETX  BCC
02  53  57  20  3E  30  30  30  34  03  1D
```

### EXAMPLE OF WRITING STATUS WORD

(self-tuning in progress)

HOST:

```
EOT 0  0  1  1  STX  S  W  blank  >  0  0  2  0  ETX  BCC
04  30  30  31  31  02  53  57  20  3E  30  30  32  30  03  1B
```

MPT instrument:

```
ACK
06
```

## 6.7 RAMP PROGRAMMING WITH SERIAL LINE

To program ramp functions with serial line, follow this procedure.

Transmit from host the code RX followed by the ramp number to program.

Transmit from host the code X1, X2, X3, ..., X8 to program the duration of the steps of the selected program.

Transmit from host the code Y1, Y2, Y3, ..., Y8 to program the final temperature of the steps of the selected program.

## 6.8 AN EXAMPLE IN BASIC LANGUAGE

Here you can see an example of a program in Basic to read the readout of the instrument with a serial line. Program the instrument with address = 01, baud rate = 9600.

```
on error goto 20
cls
open "com1: 9600, n, 8, 1" for random as #1
print #1, chr$(4) + "0" + "0" + "1" + "1" + "S" + "P" + chr$(5)
print "waiting for answer ..."
cls
a$ = input$(11, #1)
b$ = mid $(a$, 4, 7)
print
print "readout: ";b$
end
20 print "nothing received"
resume
```



## **7.0 PASSWORD FUNCTION**

The user can save the programmed parameters from untoward changes by using the "Password" function. There are two password, one for main menu and another for ramp menu.

The instrument is requested with the password = 0, but any number between 0 and 9999 can be set up as access point to change the functioning data.

In practice the password is requested each time the user enters the programming menu. With a wrong password the user can't modify the parameters but only read them.

**ATTENTION.** The number which will be programmed under the "CPAS" (for main menu) or "CPAR" (for ramp menu) reading, by the user, must be written under the "PASS" (for main menu) or "PASR" (for ramp menu) heading each time that one goes to the programming menu for the changing of the variables.  
If the user cannot recognize the exact "secret" number, it is necessary to call the customer service centre to check the instrument.

## **8.0 DEFAULT PARAMETERS (dEF)**

To reset to factory default parameters you can use the "dEF" function, which sets up all the programming parameters at the factory value, eliminating all the error situation .

BE CAREFUL: all previous programmed values will be lost.



## **9.0 NOTES**

The instrument does not have a power on switch and an internal fuse, but it immediately switches on when the correct voltage is applied (see the operating voltage on the instrument label). Keep the power line separate from the signal lines.

For security reasons, it is necessary to provide externally a two phases switch and a protective fuse near the instrument with easy access for the user.

Avoid the presence of other power elements, humidity, acid, heat sources, etc..

Mect srl is not responsible for damages to humans or goods for an improper use of the instrument or not conforming to the characteristics of its instrument..

In mect srl there is a customer service.